

SimplyShade™

BY  TREASURE GARDEN

Santorini

Cantilever

10' Round / SSAG9-10



Instruction Manual


Thank you for your purchase of Simply Shade's Santorini Cantilever Umbrella.

Please remove all contents from the package, inspect and review checklist.

CAUTION: To reduce personal injury and damage to your umbrella, read and follow this assembly and operation guide. We recommend a two-person team for assembly and disassembly. *Save information for future reference.*

CHECKLIST

- | | | |
|----------------------|------------------|-----------------|
| A - Bottom Pole Stem | E - Release Knob | I - Hub |
| B - Base Pole Clamp | F - Bar Handle | J - Center Pole |
| C - Bottom Pole | G - Support Arm | |
| D - Crank Handle | H - Canopy | |



REQUIRED FOR ASSEMBLY:

- One (1) 1/2" socket wrench or adjustable wrench.
- Four (4) 50 lb. weights - square stones or concrete weights. (200 lb. total weight needed for support - **weights not included**) Stones & weights, standard sizes can be used up to 18" L x 18" W x 1.5" H.

NOTE: Using the cross bar stand without weights will damage your umbrella and may cause injury.

STEP 1 Opening Umbrella

Lift support arm and push forward until arm locks into place. **NOTE:** May be necessary to slightly open ribs and gently shake out canopy and ribs prior to fully opening canopy for the first time. Crank handle clockwise until canopy is fully opened. **CAUTION:** Stop turning the crank handle as soon as the canopy is completely open and the hub on the center pole has reached its maximum height.

STEP 2 Tilt and Rotating Umbrella

To rotate the umbrella, loosen the base pole clamp located on the bottom pole. Rotate the umbrella to the desired position. Re-tighten the base pole clamp to lock into place.

To tilt the umbrella, loosen the release knob and tilt the canopy to desired position with the help of the bar handle. Re-tighten the release knob to lock into place.

STEP 3 Closing Umbrella

When closing the umbrella, the canopy must be in a horizontal position, or damage to umbrella may occur. Turn the crank handle counter-clockwise until the umbrella is fully closed. Loosen the release handle and pull the support arm back and guide the umbrella back to the bottom pole.

SAFETY PRECAUTIONS :

- Close the umbrella in windy conditions or when a storm approaches. Never allow the umbrella to flap in the wind; this could damage the canopy.
- Do not leave open umbrella unattended. If damage occurs, this is not covered by the warranty.
- When adjusting the umbrella, make sure that no person(s) or item(s) are close to the umbrella. This is important to prevent injury or material damage.

CARE AND MAINTENANCE :

- When not in use, close and cover umbrella with a protective cover (sold separately).
- Allow a wet canopy to dry opened up.
- If necessary, clean the fabric with lukewarm water, mild detergent, and a sponge.
- Wipe sliding marks on the aluminum poles with a damp cloth.

Winter Storage:

- Store in a dry, protective place.
- Any visible defects must be repaired by a professional.

After the Winter:

- Areas subject to turning and sliding can be treated with a non-staining lubricant spray (silicone-based).
- Check the condition and function of the umbrella. Any defects must be repaired by a professional.

WARRANTY:

The manufacturer warrants that this umbrella, when subject to normal and proper use, will be free from manufacturing defects for a period of one year from the original date of purchase. Should any defect occur during the specified time period, the manufacturer will repair, replace, or provide replacement parts, at its own option. Limited warranty against fabric fading, based on fabric grade. Warranty is not transferable.

We will not warrant any claim coverage unless both the original sales receipt and request form are sent to us. Any items that are returned for warranty or non warranty purposes must be issued a Return Authorization Number. Only

upon issuance of an RA # and inspection by our QC department will credit or replacement of umbrella be issued. It is the customer's responsibility to pay the freight on return products or replacement parts. ALL RETURNED ITEMS MUST INCLUDE THE RA# CLEARLY WRITTEN ON THE RETURN PACKAGE or package will be refused by our warehouse personnel.

NOTE: Damages and failure caused by improper use due to neglect of reasonable and necessary care are not covered by this warranty.

Additionally, acts of nature (including but not limited to wind, hurricanes, tornadoes, and storms) are not covered by this warranty.

SimplyShade[®]
BY TREASURE GARDEN

www.simplyshade.com

©2014 Simply Shade - All Rights Reserved.

12/14